



기능 소개

1. LED 표시등
2. Micro 인터페이스
3. 스위치를 돌려서 열림
4. 스위치를 돌려서 개짐

기술 파라미터

- 배터리: 602030 리튬이온 폴리머 300mAh
- 마이크보 입력: 5V/1A
- 스피커: φ40mm/4Ω 3W
- 블루투스 버전: V4.2
- 대기 시간: 최대 1.5시간
- 충전 시간: 3시간까지
- 방진방수 IP64
- 블루투스 매칭명: XJ0823

제품 사양:

(처음 사용하기 전에 반드시 100퍼센트로 충전을 해 주십시오).

충전

제품의 충전선을 전원과 오디오의 마이크 포트에 연결하세요. ①충전 시 LED 표시등은 빨간색으로 표시되며, 충전 후 불이 꺼집니다.

블루투스 설정

- 왼쪽에서 'on' 버튼을 누르면 LED 표시등이 파란색으로 깜박입니다.
- 대기 중이면 LED가 파란색으로 빠르게 깜박입니다.
- 모바일 장치의 블루투스 기능을 켜고 XJ0823 매칭명을 선택합니다.
- 매칭이 성공한다면, LED는 파란색으로 계속 켜질 겁니다.
- 음악을 재생 시 파란 LED가 서서히 깜박입니다.
- 오른쪽에서 'OFF' 버튼을 누르면 설비를 닫습니다.

안전 주의 사항:

광고-사용시 항상 기본적인 예방조치를 지켜야 합니다:

1. 사용 전에 모든 삽화를 읽어 보세요.
2. 본 제품은 온도가 32°F 이하(0°C)이거나 115°F 이상(45°C)에 도달할 때까지 사용하지 않습니다.
3. 본 제품의 2 쪽은 3차 충전과 방전 순환 사이클을 완료한 후에 설비의 모든 성능을 활성화할 수 있습니다.
4. 어린이들은 부상의 위험을 줄이기 위해서 반드시 동반한 상태에서 사용하십시오.
5. 설비에 습기가 차지 않도록 하십시오.
6. 장치의 사용범위 입력 한계치 넘기지 마십시오. 과부하 입력은 화재나 부상의 원인이 될 것입니다.
7. 파손되거나 개조된 설비는 사용하지 마십시오.
8. 파손되거나 개조된 배터리는 예측할 수 없는 화재, 폭발 또는 부상 등의 위험을 유발할 수 있습니다.
9. 설비를 분해하지 마십시오. 수리를 요하는 경우, 합리적인 전문적인 서비스를 구하십시오. 부정확한 보수와 재조정은 화재나 부상의 위험이 있습니다.
10. 설비가 불 속에 노출되거나 높은 온도에 노출되지 마세요. 영하 또는 104°F 이상의 온도에서 폭발을 일으킬 수가 있습니다.



Function Introduction

1. LED lights
2. Micro input interface
3. Turn on the toggle switch
4. Turn off the toggle switch

Technical parameters

Built-in battery :602030 lithium polymer 300mAh

Micro input: 5 v / 1 a

Speaker: Φ 40 mm Ω 3 w / 4

Bluetooth :V4.2

- Playing time: up to 1.5 hours
- Charging time: up to 3 hours
- Waterproof and dustproof IP64
- Bluetooth pairing name: XJ0823

Description

(Please make sure the product is fully charged before first use).

Charge your stereo

- Connect the attached charging cable to the power supply and micro port on the stereo
When charging LED indicator red, full back light off.

Bluetooth Settings

- Turn on/off button to "on" and the LED indicator will flash blue.
- Standby LED light blue flash.
- Turn on bluetooth on your mobile device and select the XJ0823 pairing name.
- If the match is successful, the LED light will always be blue.
- Blue LED lights flash slowly when playing music.
- Right turn OFF/OFF button to "OFF" to turn OFF the device.

Safety Instructions

Warning - Always follow the basic precautions when using this product:

1. Please read all the illustrations before using.
2. Do not store the product at temperatures below 32 ° F (0 ° C) or above 115 ° F (45 ° C).
3. The full performance of the equipment can only be achieved after completing 2 or 3 charge and discharge cycles of the product
4. In order to reduce the risk of injury, children should have access to this product under supervision.
5. Keep the equipment dry.
6. Do not output the rated value beyond the scope of use of the equipment. Overload output can cause fire or injury.
7. Do not use damaged or modified equipment
8. Damaged or modified batteries may exhibit unpredictable fire behaviour, explosion or risk of injury.
9. Do not remove the equipment. If maintenance is required, seek qualified professional services. Improper maintenance and reorganization carries the risk of fire or injury.
10. Do not expose the equipment to fire or excessive temperature. Contact with an open flame or temperatures above 104 ° F .